


Setup Instructions



Note: Always roll graphic “image side out” during storage.




Remove ExpressStand™ from bag. Slide metal foot base onto bottom profile of graphic.





Assemble pole. Attach top pole connector to top profile of graphic.



Flex pole and insert bottom of pole into the hole of metal foot base.



Display can be moved and repositioned after set up.



OPTIONAL
To attach light, place into top of pole connector.